


NS50P
Infrared Sensor



Operator's Manual

| Content | Page |
|---|------|
| 1. Description----- | 2 |
| 1.1 Introduction----- | 2 |
| 1.2 Scope of Delivery----- | 2 |
| 1.3 Maintenance----- | 2 |
| 1.4 Electrical Interference----- | 2 |
| 2. Basics of Infrared thermometry ----- | 3 |
| 3. Factory Defaults----- | 3 |
| 4. Technical Data ----- | 4 |
| 4.1 Measurement Specifications ----- | 4 |
| 4.2 Electrical Specifications----- | 4 |
| 4.3 General Specification----- | 5 |
| 5. Optical Charts----- | 5 |
| 6. Dimensions----- | 8 |
| 7. Installation ----- | 8 |
| 7.1 Mechanical Installation----- | 8 |
| 7.2 Wiring ----- | 9 |
| 8. Aiming and Focusing ----- | 9 |
| 9. Operation----- | 10 |
| 10. Accessories----- | 12 |
| 10.1 Mounting Bracket ----- | 12 |
| 10.2 Air Purge Collar ----- | 12 |
| 11. Software----- | 13 |
| 12. Warranty ----- | 15 |

*Note: Read the manual carefully before the initial start-up. The producer reserves the right to change the herein described specifications in case of technical advance of the product.

4. Technical Data

4.1 Measurement Specifications

| Model | Temperature Range | Spectral Response | D:S (90%) |
|-------|-------------------|-------------------|-------------------|
| LT | 0°C ~ 900°C | 8 ~ 14µm | 60:1(SF)/75:1(CF) |
| LR | 0°C ~ 1300°C | 8 ~ 14µm | 120:1 |
| H1 | 600°C ~ 1600°C | 1 µm | 300:1 |
| H2 | 300°C ~ 1300°C | 1.6µm | 300:1 |
| H3 | 100°C ~ 600°C | 2.3µm | 140:1/120:1(FF) |


| | |
|---------------------|---|
| Response Time (95%) | LT/LR=150 ms, H1/H2/H3=5ms |
| Accuracy*1 | LT/LR= ±1% of reading or ±1.5°C, which is greater H1/H2/H3= ±(0.5% of reading+2°C) |
| Repeatability*1 | LT/LR= ±0.5% of reading or ±1°C, which is greater H1/H2/H3= ±(0.5% of reading+2°C) |
| Emissivity | 0.100 ~ 1.000 |

*1 At 23±5°C · emissivity LT/LR=0.95, H1/H2/H3=1.00

4.2 Electrical Specifications

| | |
|-----------------------|-----------------------|
| Signal Output | 4 ~ 20mA |
| Digital Communication | TTL / USB(optional) |
| Max. Loop Resistance | 500Ω |
| Power Supply | 24 VDC ±20%, < 100 mA |
| Display | 6 digit backlit LCD |

6. Dimensions



7. Installation

7.1 Mechanical Installation

The NS50P comes with a standard 3 m cable, a mounting and fixed mounting bracket. You can mount the sensor in brackets or cutouts of your own design. For easy mounting and aligning the sensor to the measured object a fixed or adjustable mounting bracket is available.


For exact measurement of the object temperature the sensor must be aligned correctly onto the object. Mount the sensor so the measured spot is the same or smaller than the target.

4.3 General Specification

| | |
|----------------------|---------------------------|
| Environmental Rating | IP 65 |
| Ambient Temperature | 0°C ~ 70°C |
| Storage Temperature | -20°C ~ 80°C |
| Relative Humidity | 10% ~ 95% |
| Cable Temperature | -20°C ~ 80°C |
| Cable Length | 3m (standard), 5m, or 10m |
| Weight | 500g (without cable) |

5. Optical Charts

The optical diagrams indicate the target spot diameter at any given distance between the target object and the sensing head. The spot size will change in longer distance corresponding to the following drawing. In order to prevent measuring errors the object must be as least as big as the spot size.



1. Description

1.1 Introduction

The NS50P is a non-contact infrared temperature sensor. The electronics are protected by a rugged IP65 aluminium alloy(A6061) housing. They calculate the surface temperature based on the emitted infrared energy of objects and convert the energy into temperature signal.

1.2 Scope of Delivery




- NS50P
- Mounting nut x 1
- Fixed mounting bracker x 1
- 3m connection cable (standard, 4-cores)
- User manual

1.3 Maintenance

Keep the lens clean at all times. Any foreign matter on the lens would affect measurement accuracy. The lens surface can be cleaned with a soft, humid tissue moistened with water or a water based glass cleaner. Never use cleaning compounds which contain solvents for the lens.

1.4 Electrical Interference

Keep away from strong EMF (electromagnetic fields). Avoid static electricity, arc welders, and induction heaters. Avoid abrupt changes of the ambient temperature. To avoid ground loops, make sure that only one point is earth grounded.






2. Basics of Infrared thermometry

Infrared thermometer is an optoelectronic sensor. Any object of a temperature above absolute zero (-273 °C) emits electromagnetic radiation. Infrared thermometer calculates the surface temperature on the basis of the emitted infrared radiation from the object. By determining its radiation intensity the temperature of an object can thereby be determined in a non-contact way.


3. Factory Defaults

| | |
|-------------------|-----------------------------|
| Emissivity | LT/LR=0.95 H1/H2/H3=1.00 |
| Average | LT/LR=0.2 H1/H2/H3=0 |
| Peak Hold | inactive |
| Valley Hold | inactive |
| Advance Peak Hold | inactive |
| Unit | °C |

Factory Default Setting :
Press the down (v) key (keep pressed), and then the up (Λ) key. The display will appear INIT for confirmation.



9. Operation




| Display | Mode | Adjustment Range |
|--|--|----------------------------------|
| S ON | Laser Sighting (ON) / (OFF) | Press the Down (v) or Up (Λ) key |
| E 1.000 | Emissivity | 0.100 ~ 1.000 |
| A 0.2 | Signal output average | 0.0 ~ 600.0s |
| P 0.0 | Signal output Peak hold (inactive) | 0.0 ~ 600.0s |
| V 0.0 | Signal output Valley hold (inactive) | 0.0 ~ 600.0s |
| AP OFF | Advanced Peak hold (inactive) | ON / OFF |
| AP xxx | Trigger value for AP | depending on user |
| The signal processing features (Peak, Valley and AP hold) cannot be used concurrently. | | |
| L xxx | Lower Limit signal output [4mA] | depending on model |
| H xxxx | Upper Limit signal output [20mA] | |
| Unit C | Temperature unit | °C / °F |

Sensor Setup :


1. Pressing the up (Λ) key and down (v) keys simultaneously to enter setup function.
2. Press the down (v) key, when a (-) symbol appears at the right side of the selected function confirming into Setting Mode.
3. Press the down (v) or up (Λ) key to select the functional parameter.
4. No action for 7s forces the unit to leave the Setting Mode and save the parameter.
5. Laser ON/OFF : Pressing the down (v) key to switch laser sighting on or off.

10. Accessories

10.1 Mounting Bracket



10.2 Air Purge Collar



11. Software

11.1 Install driver for USB Adapter :

Please install the driver for USB cable first. After connecting the USB adapter cable to your PC, the system will allocate the infrared thermometer adapter driver automatically.

To find out which COM-Port number your computer set, open the device manager (Start – Settings – Control Panel – System – Hardware – Device Manager). In the category “Ports (COM & LPT)” you can find the “Infrared Thermometer Adapter (DR 6.x)” (only if your USB adapter is plugged in). In parenthesis the COM Port number is shown.

11.2 STonline Software

- 1) Please connect the sensor to your PC and start STonline software, and open at first [Menu: Setup(S)\Interface Settings], to choose the correct Com port and set the Baud Rate to 115,200.

After the unit connected to your personal computer, and the STonline software is started successfully, the communication has been established. The status line will be displayed in the left bottom: active COM port and successfully communication with the connected sensor. And the target temperature will show on the left in digital form.

- 2) Starting the measurement
Please press the measuring key:
[Menu:Measurement(M)\ Start]

- 3) Scaling of the temperature axis
In the menu item settings [Diagram(A)]
Global Auto Scaling: the temperature range of the diagram is automatically adapted to the respective peak values.
Local Auto Scaling: the temperature range of the diagram will be dynamically adapted to the respective peak values.
Manual scaling: It can be done at any time using the control elements of the temperature axis.

- 4) Stop the measurement
To stop the current measurement, please press the stop key [Menu:Measurement(M)\ Stop].
The save key [Menu: File(F)\Save Diagram] opens an explorer window to select destination and file name.

- 5) Diagram setting
The menu item settings [Menu: Diagram(A)\Settings] enable the settings for data diagram.
Color: temperature graph and digital display.
Initial Time Interval(S): time frame on x-axis at the beginning of measurement.

12. Warranty

Each product passes through a quality process. Nevertheless, if a failure occurs please contact the customer service at once. The period of warranty starts from the date of delivery of the product to the customer and shall cover a period of 12 months. This warranty shall not apply to fuses, batteries, or any product that has been subject to misuse, neglect, accident, or abnormal conditions of operation.

The manufacturer shall not be liable for any special, incidental or consequential damages, whether in contract, tort, or otherwise. If a failure occurs during the warranty period, the product will be replaced, calibrated or repaired without further charges. The freight costs will be paid by the sender. The manufacturer reserves the right to exchange components of the product instead of repairing it.

If the failure results from misuse, neglect, accident, or abnormal conditions of operation or storage, the user has to pay for the repair. In that case you may ask for a cost estimate beforehand.

Test Standards:
- EN 61010-1:2010
- EN 61326-1:2013
Complies with the following relevant provisions:
- EC Low Voltage Directive (2014/35/EU)
- EC Electromagnetic Compatibility Directive (2014/30/EU)

SENTEST Instruments Corporation Ltd.
Tel : + 886-2-2579-5079
Fax : + 886-2-2579-5297
www.sentest.com



NS50P-E202009A